

SAMPLE TEST QUESTIONS BRICKLAYER - ITA WEBSITE

- 1 Which chisel is used to remove deteriorated mortar joints in restoration work?
 - A. Cold.
 - B. Pointing.
 - C. Plugging.
 - D. Brick set (bolster).

- 2 A room is 12 m × 9 m. What should be the diagonal measurement to ensure that the room is square?
 - A. 9 m
 - B. 12 m
 - C. 13 m
 - D. 15 m

- 3 How much flagstone is required for a 2 000 m × 4 000 mm patio if 1 t covers 1.5 m²?
 - A. 2.3 t
 - B. 4.0 t
 - C. 5.3 t
 - D. 12.0 t

- 4 What is the procedure for mixing a muriatic acid solution to clean brick?
 - A. Mix the water into the acid.
 - B. Mix the acid into the water.
 - C. Mix the acid into a soapy water solution.
 - D. Mix soapy water solution into the acid.

SAMPLE TEST QUESTIONS BRICKLAYER - ITA WEBSITE

- 5 What is the procedure to lay out a block foundation?
- A. Place marks on footings indicating size of wall and square up with benchmark.
 - B. Plumb down from batter boards to find corners, find bond for blocks to be laid, and determine elevation of corners.
 - C. Place centre marks on footing of foundation, cut blocks for corners, then square corners of foundation.
 - D. Place lines on batter boards to get building lines, plumb down from intersection of lines to find corners, then determine bond.
- 6 How many standard blocks are required per course on a 7 200 mm long wall?
- A. 16
 - B. 18
 - C. 32
 - D. 36
- 7 How should a bed joint be spread for the first course in a non-reinforced concrete block foundation?
- A. Full bed.
 - B. Less than 5 mm thick.
 - C. More than 25 mm thick.
 - D. Using face shell bedding.
- 8 What is the ratio of Portland cement, lime and sand to produce type S mortar?
- A. 1 part Portland cement, 1/2 part lime, 4 1/2 parts sand.
 - B. 1 part Portland cement, 1 part lime, 6 parts sand.
 - C. 1 part Portland cement, 2 parts lime, 9 parts sand.
 - D. 1 part Portland cement, 4 part lime, 9 parts sand.

SAMPLE TEST QUESTIONS BRICKLAYER - ITA WEBSITE

- 9 Which types of mortar should be used to build a brick veneer wall?
- A. M or K
 - B. S or N
 - C. K or O
 - D. S or M
- 10 How much grout is needed to fill a 20 mm cavity for a 3.0 m × 5.2 m wall?
- A. 0.231 m³
 - B. 0.295 m³
 - C. 0.312 m³
 - D. 0.362 m³
- 11 Concrete block is laid out so that each course gauges at 200 mm. How high will the wall be after 26 courses?
- A. 2.6 m
 - B. 3.8 m
 - C. 4.2 m
 - D. 5.2 m
- 12 What must be done to the substrate in a cavity wall system when preparing for application of a peel and stick membrane?
- A. It is primed.
 - B. It is sandblasted.
 - C. It is power washed.
 - D. It is etched with acid.
- 13 How is rigid insulation installed in a cavity wall system?
- A. With a 25 mm air space.
 - B. With a 50 mm air space.
 - C. Tight to the back-up wall.
 - D. Tight to the exterior wythe.

SAMPLE TEST QUESTIONS BRICKLAYER - ITA WEBSITE

- 14 What is the maximum allowable spacing for weep holes installed in veneer?
- | | METRIC | | IMPERIAL |
|----|---------------|----|-----------------|
| A. | 400 mm | A. | 16 in. |
| B. | 600 mm | B. | 24 in. |
| C. | 800 mm | C. | 32 in. |
| D. | 1 000 mm | D. | 40 in. |
- 15 Which type of fastener is used to attach wall ties to a wood frame structure?
- A. Common nail.
 - B. Carriage bolt.
 - C. Wood screw.
 - D. Machine screw.
- 16 At which stage of wall construction are wall plates and bearing plates installed?
- A. After the wall is set.
 - B. While the wall is being built.
 - C. After the scaffolding is removed.
 - D. While the steel members are being installed.
- 17 How many control joints are needed in a 75 m foundation wall?
- A. 2
 - B. 3
 - C. 4
 - D. 5
- 18 What is done to prevent concrete blocks from shifting on a retaining wall?
- A. Pour grout into the first course.
 - B. Horizontally reinforce the first course.
 - C. Lay the first course in the footing concrete while it is fresh.
 - D. Install vertical dowels and grout at spaced intervals in the footing.

SAMPLE TEST QUESTIONS BRICKLAYER - ITA WEBSITE

- 19 What must be done when placing joint reinforcing in a block wall at a control joint?
- A. Place the wire through the joint.
 - B. Overlap the wire through the joint.
 - C. Stop the wire both sides of the joint.
 - D. Stop the wire a metre from the joint.
- 20 How are prefabricated masonry panel curtain walls fastened to a steel frame structure?
- A. Using metal veneer wall ties.
 - B. Using masonry ties built onto the floor levels.
 - C. By welding or bolting angle iron clips to the frame.
 - D. By interlocking concrete beams from the structure into the masonry wall.
- 21 Which type of chisel is used to dress stone edges?
- A. Comb.
 - B. Point.
 - C. Pitch.
 - D. Plug.
- 22 How is the bedding plane of cut ashlar stone laid?
- A. Parallel to the bed joints.
 - B. Parallel to the cross joints.
 - C. Diagonally to the bed joints.
 - D. Diagonally to the cross joints.
- 23 What is the minimum height above the chimney cap that chimney lines must extend?
- A. 25 mm
 - B. 38 mm
 - C. 50 mm
 - D. 75 mm

SAMPLE TEST QUESTIONS BRICKLAYER - ITA WEBSITE

- 24 What is the procedure to install refractory plastic on a wall?
- A. Install several slabs at a time and ram.
 - B. Build forms, fill with plastic and ram the top.
 - C. Install in layers ramming each slab individually.
 - D. Build forms and ram plastic in one box at a time.
- 25 What is done to ensure a good bond when preparing a wall for tuck-pointing?
- A. Power wash the entire surface.
 - B. Clean and wet down the area.
 - C. Remove and replace the defective mortar.
 - D. Remove defective mortar, clean and dampen joints.
- 26 Which type of mortar is used for re-pointing historical clay brick masonry where there is **no** high lateral load?
- A. N
 - B. S
 - C. K
 - D. M
- 27 What is required under the base course when starting a glass block panel?
- A. Wood base.
 - B. Metal angle.
 - C. Metal channel.
 - D. Asphalt emulsion.
- 28 How many radius points are used on a gothic arch?
- A. 1
 - B. 2
 - C. 3
 - D. 4

SAMPLE TEST QUESTIONS BRICKLAYER - ITA WEBSITE

- 29 What is done to release frame wedges in arch construction?
- A. Tap outward.
 - B. Jack up frame.
 - C. Cut template into pieces.
 - D. Strike template with sledge.
- 30 What is the sequence to re-joint points after removing the template?
- A. Wet joints, parge soffit and re-joint.
 - B. Wet joints and slick over hard mortar.
 - C. Cut out joints, brush, wet and re-point.
 - D. Cut out joints with sledge and re-point.